

**1. Enable STK**

a. AT+QSTK=1

**2. Setup Menu**

a. AT+STKTR="810301250082028281830100"

**3. FOR PROFILE CONFIG**

a. AT+STKENV="D30782020181900101"

**4. AIRTEL Profile to BSNL profile**

- **Second profile Selection**

a. AT+STKTR="810301240082028281830100900102"

- Display Text

a. AT+STKTR="810301210182028281830100"

- Refresh

a. AT+STKTR="810301010482028281830100"

**5. BSNL profile to AIRTEL profile**

- Frist profile Selection

a. AT+STKTR="810301240082028281830100900101"

- Display Text

a. AT+STKTR="810301210182028281830100"

- Refresh

a. AT+STKTR="810301010482028281830100"