

Firmware version: L26TNR01A03

\$PSTMCFGMSGL,<listid>,<rate>,<listlow>,<listhigh> //This command configures the message list.

Query the default status:

\$PSTMGETPAR,1201 //query listlow

\$PSTMSETPAR,1201,0x00180056*5B //response

\$PSTMGETPAR,1228 //query listhigh

\$PSTMSETPAR,1228,0x7ec20010*58 //response

Enable the output of (\$PSTMTG+\$PSTMTS+\$PSTMPPSDATA+\$PSTMUTC) sentence:

//The bitmask of \$PSTMTG message is 0x100, low 32 bits.

//The bitmask of \$PSTMTS message is 0x200, low 32 bits.

//The bitmask of \$PSTMPPSDATA message is 0x200000, low 32 bits.

//Then,0x00180056+ 0x100+0x200+0x200000=0x380356

//The bitmask of \$PSTMUTC message is 0x4, high 32 bits.

//Then,0x7ec20010+0x4=0x7ec20014

\$PSTMCFGMSGL,0,1,00380356,7ec20014

\$PSTMSAVEPAR

\$PSTMSRR